


Roland
E-X10
ARRANGER KEYBOARD

Owner's Manual



Before using this unit, carefully read “USING THE UNIT SAFELY” and “IMPORTANT NOTES” (the leaflet “USING THE UNIT SAFELY”). After reading, keep the document(s) where it will be available for immediate reference.

Copyright © 2023 ROLAND CORPORATION

Intellectual Property Right


- It is forbidden by law to make an audio recording, video recording, copy or revision of a third party’s copyrighted work (musical work, video work, broadcast, live performance, or other work), whether in whole or in part, and distribute, sell, lease, perform, or broadcast it without the permission of the copyright owner.
- Do not use this product for purposes that could infringe on a copyright held by a third party. We assume no responsibility whatsoever with regard to any infringements of third-party copyrights arising through your use of this product.
- The copyright of content in this product (the sound waveform data, style data, accompaniment patterns, phrase data, audio loops and image data) is reserved by Roland Corporation.
- Purchasers of this product are permitted to utilize said content (except song data such as Demo Songs) for the creating, performing, recording and distributing original musical works.
- Purchasers of this product are NOT permitted to extract said content in original or modified form, for the purpose of distributing recorded medium of said content or making them available on a computer network.
- Roland is an either registered trademark or trademark of Roland Corporation in the United States and/or other countries.
- Company names and product names appearing in this document are registered trademarks or trademarks of their respective owners.

Contents

Panel & Display Description	4	Arpeggiator	17
Front Panel	4	Turn the Arpeggiator on or off	17
Rear Panel	5	Set the Split Point of Arpeggiator	17
LCD	5	Mixer	17
Setup	6	Quick Memory	18
Power Supply	6	Registering the Panel Settings	18
Setting a Music Rest	6	Recalling the Registered Settings	18
Connections	7	One Touch Setting	18
Connecting a Computer	7	Chord Dictionary	19
Connecting a Pedal Switch	7	Playing Songs	19
Connecting a Pair of Headphones	7	Listening to Songs	19
Connecting an Audio Equipment	7	Lesson Mode	20
Connecting an Audio Player	7	Recording and Playing Back	20
Connecting a Microphone	7	Function Menu	21
Power / Master Volume	8	Tune	21
Turning the Power On / Off	8	Octave	21
Adjusting the Master Volume	8	Split Point	22
Playing Demo Song	9	Beat Type	22
Playing Tones	10	Touch Response	22
Selecting a Tone	10	Modulation	22
Playing Two Tones Simultaneously	10	DSP	22
Playing Different Tones with Both Hands	10	Reverb Type	23
Touch Response	11	Reverb Level	23
Modulation	11	Chorus Type	23
Sustain	11	Chorus Level	23
DSP	11	Tempo Remain	23
Transpose	11	Auto Off	23
Piano Mode	12	MIDI	24
Auto Accompaniment	12	The main application of MIDI	24
Selecting Chord Modes	12	Connecting to a MIDI Software on Computer	24
Playing Auto Accompaniment (Rhythm Track)	13	Troubleshooting	25
Playing Auto Accompaniment (All Tracks)	13	Specifications	26
Accompaniment Sections	13	Tone list	27
Fade In / Out	14	Style List	33
Accompaniment Volume	14	Song List	35
Chord Fingering	15	MIDI Implementation Chart	37
Tempo	16		
Metronome	16		

Panel & Display Description


Front Panel



1. **[POWER] switch**
Switches the power on or off.
2. **[VOLUME] knob**
Adjusts the master volume.
3. **[CHORD] button**
Lets you access the Chord mode.
4. **[LESSON] button**
Lets you access the Lesson mode.
5. **[CHORD DICT.] button**
Turns the chord dictionary on or off.
6. **[SYNC] button**
Turns the sync function on or off.
7. **TEMPO[-]/[+] buttons**
Adjusts the current tempo.
8. **[START/STOP] button**
Starts or stops playing the style.
9. **[INTRO/ENDING] button**
Plays the intro or ending.
10. **[FADE] button**
Turns fade-in or fade-out on or off.
11. **[FILL A] button**
Plays fill A.
12. **[FILL B] button**
Plays fill B.
13. **[QUICK MEMORY] button**
Registers the panel settings.
- 14~17. **[1]~[4] buttons**
Recalls a registered panel setting.
18. **[O.T.S.] button**
Turns one touch setting function on or off.
19. **[STYLE] button**
Lets you access the Style mode.
20. **[TONE] button**
Lets you access the Tone mode.
[ARP. (⊙↘)]
Press and hold to turn arpeggiator on or off.
21. **[DUAL] button**
Turns the dual function on or off.
22. **[SPLIT] button**
Turns the split function on or off.
23. **[TRANSPOSE] button**
Adjusts the transpose setting.
24. **[SUSTAIN] button**
Turns the sustain function on or off.
[MODULATION (⊙↘)]
Press and hold to turn modulation on or off.
25. **[MIXER] button**
Lets you access the Mixer menu.
26. **[MENU] button**
Lets you access the Function menu.
27. **[SONG] button**
Lets you access the Song mode.
28. **[▶/■] button**
Song mode: plays/pauses the song.
Other mode: plays/pauses the recorded song.
[REC (⊙↘)]
Press and hold to enter the Record mode.
29. **[METRONOME] button**
Turns the metronome on or off.
30. **[PIANO] button**
Lets you access the Piano mode.
31. **[<]/[>] and Numeric buttons:**
Select the number or set parameter values.


Panel & Display Description

Rear Panel



- | | |
|---|---|
| <p>32. USB COMPUTER jack
For connecting to a computer.</p> <p>33. PEDAL jack
For connecting a pedal switch.</p> <p>34. PHONES/OUTPUT jack
For connecting external audio equipment.</p> | <p>35. AUX IN jack
For connecting external audio source, such as an MP3.</p> <p>36. MIC INPUT jack
For connecting a microphone.</p> <p>37. DC IN jack
For connecting the DC 12V power adaptor.</p> |
|---|---|

LCD



- | | |
|---|---|
| <p>1. RECORD / PLAY / MODULATION</p> <p>2. NUMBER</p> <p>3. TONE / STYLE / DEMO / SONG</p> <p>4. CHARACTERS</p> <p>5. ARP. / TOUCH / SUSTAIN</p> <p>6. RECORD</p> <p>7. TREBLE CLEF</p> <p>8. BASS CLEF</p> | <p>9. MEASURE</p> <p>10. BEAT</p> <p>11. TEMPO</p> <p>12. CHORD</p> <p>13. MEMORY / O.T.S.</p> <p>14. A.B.C. / WHOLE / FADE / A/B</p> <p>15. NOTE INDICATION</p> <p>16. LESSON</p> <p>17. DUAL / SPLIT / DSP</p> |
|---|---|

Setup

This section contains information about setting up your instrument and preparing to play. Please go through this section carefully before turning the power on.

Power Supply

You can power the instrument by using the included power adaptor or by using batteries.

Turn down the volume of the instrument and the connected audio equipment before you switch the instrument on.

Using Power Adaptor

1. If the included power adaptor is interchangeable plug type, choose the included adaptor plug that fits the type of AC outlet used in your region. Follow the image to put the adaptor plug into the grooves of the power adaptor unit and rotate the adaptor plug clockwise to lock. If the included power adaptor is not interchangeable plug type, skip this process.
2. Connect the adaptor to the DC 12V jack of this instrument.
3. Plug the adaptor into an AC outlet.
4. Press the [POWER] switch, the LCD screen turns on, indicating the instrument is powered on.
5. If you are ready to turn off the instrument, press and hold the [POWER] switch again.

Notes:

1. The power to the instrument will be turned off automatically after a pre-determined amount of time has passed since it was last used for playing music, or its buttons or controls were operated (Auto Off function). If you do not want the power to be turned off automatically, disengage the *Auto Off* function (p. 23).
 - The recorded song and the registered memory will be lost when the power turns off.
 - To restore power, turn the power on again.
2. For your safety, please unplug the instrument when it is not in use or during a thunderstorm.

Using Batteries

This instrument requires six AA size or equivalent alkaline batteries for power supply.





1. Open the battery compartment cover located on the bottom of the instrument.
2. Insert the batteries. Carefully follow the polarity markings on the cabinet.
3. Replace the compartment cover. Make sure it locks firmly in place.

Notes:

1. Do not mix used and new batteries.
2. Always use same types of batteries.
3. Remove the batteries from the instrument when it is not being used for an extended period of time.
4. When turning the unit over, be careful so as to protect the buttons and knobs from damage. Also, handle the unit carefully; do not drop it.

Setting a Music Rest

A music rest is supplied with the instrument. You can easily attach it by inserting it into the slots at the rear of the panel.



Connections


Connecting a Computer

The instrument receives and transmits MIDI messages via the USB COMPUTER jack.

Use a USB cable to connect the instrument to a computer.

Notes:

1. Do not set the USB MIDI device to be both input and output simultaneously when configuring the software on your computer. Otherwise, the sound will be overlapped when playing the keyboard.
2. Using a USB2.0 interface is recommended when connecting the instrument to a computer.




Connecting a Pedal Switch

A pedal switch can be plugged into the PEDAL jack, and you can use it to turn the sustain on or off.

When you step on the pedal, all notes you play on the keyboard will have a longer sustain.

Note:

Please connect the plug of the pedal to the PEDAL jack before turning the power on. The polarity of different pedals may vary. If the connected pedal switch works in reversed behavior, please plug the pedal to the PEDAL jack before turning the power on.




Connecting a Pair of Headphones

A standard pair of stereo headphones can be connected to the PHONES/OUTPUT jack for private practice or late-night playing.

The internal stereo speaker system is automatically shut off when a pair of headphones is plugged into this jack.

Note:

To avoid the risk of hearing loss, do not listen with headphones at high volume level for a long period of time.




Connecting an Audio Equipment

The PHONES/OUTPUT jacks deliver the output of the instrument to external audio equipment, such as a keyboard amplifier, a stereo sound system, a mixing console, or a tape recorder. Use an audio cable to connect the OUTPUT of the instrument to the AUX IN of the external audio equipment.

Note:


To avoid damaging the speakers, please set the volume level to minimum before connecting to power and other devices.



Connecting an Audio Player

The AUX IN jack receives audio signals from an external audio source such as a Smart Device, MP3 or CD player.

Use an audio cable to connect the AUX IN of the instrument to the OUTPUT of an audio player. The instrument's speakers will play the music transmitted from the external player, and you can play along.




Connecting a Microphone

Before connecting or disconnecting a microphone, set the master volume to minimum level.

Plug a microphone into the MIC INPUT jack, then adjust the master volume to an appropriate level.

Note:

Please unplug the microphone when it is not used.



Power / Master Volume

Turning the Power On / Off

1. Make sure the instrument is properly connected to power supply.
2. Press the [POWER] switch, the LCD screen turns on, indicating the instrument is powered on.
3. If you are ready to turn off the instrument, press and hold the [POWER] switch again.




Note:

If the LCD isn't lit after you turn on the power, please check the power connection.

Adjusting the Master Volume

Rotate the [VOLUME] knob clockwise to increase the master volume or counter-clockwise to decrease it. Adjust to set the desired volume level.



Note:



If the instrument keeps silent, check if the volume has been set to minimum or if headphones are plugged into the PHONES/OUTPUT jack.

Playing Demo Song

1. Press the [METRONOME] + [PIANO] buttons simultaneously to loop playing all demo songs. The LCD displays the current demo number and name.
2. Use the numeric buttons or [<]/[>] buttons to select a demo song.
3. Press the [METRONOME] + [PIANO] buttons again to stop playing and exit demo song.
Or you can press the [START/STOP] button to stop playing and exit demo song.

Note:

While demo song is playing, all buttons and keys are unavailable except [<]/[>], Numeric buttons, [START/STOP], TEMPO[-]/[+], [VOLUME], [METRONOME] + [PIANO], and the [POWER] switch.



Playing Tones


The instrument features a variety of built-in tones. Please refer to the “Tone List” (p. 27).

Selecting a Tone

1. Press the [TONE] button to enter Tone mode.
The “TONE R1” icon on LCD lights up. The LCD displays the current tone name and number.
2. Use the numeric buttons or [←]/[→] buttons to select a tone.
3. Play the keyboard to use the tone for performance.

Note:


When Dual and Split functions are in use, you can press the [TONE] button repeatedly to switch between the tone layers.



Playing Two Tones Simultaneously

The dual function can layer two different tones together, creating a much richer sound.

1. Press the [DUAL] button to turn on the dual function.
The “TONE R2” and “DUAL” icons on LCD light up. The LCD displays the current name and number for R2.
2. Use the numeric buttons or [←]/[→] buttons to select a tone for R2.
3. Play the keyboard. You will hear two different tones layered together. It seems like two different instruments playing at the same time.
4. Press the [DUAL] button again to turn off the dual function.




Playing Different Tones with Both Hands

This function splits the keyboard into the left and the right hand areas, each with a different tone. The left hand tone is the split tone. The default split point is F#3 (19). You can set the split point to any key as required. Please refer to Split Point in the “Function Menu” (p. 21).

1. Press the [SPLIT] button to turn on the split function.
The “TONE L” and “SPLIT” icons on LCD light up. The LCD displays the current split tone name and number.
2. Use the numeric buttons or [←]/[→] buttons to select a split tone.
3. Play the keyboard with both hands. You will hear two different tones.
4. Press the [SPLIT] button again to turn off the split function.

Notes:

1. When the keyboard is split, only the right hand area will use the dual tones.
2. You can set the volume level for each tone layer in the mixer menu. Please refer to “Mixer” (p. 17).




Playing Tones

Touch Response

The touch response feature lets you dynamically and expressively controls the level of the sound with your playing strength- just like playing on an acoustic instrument.

You can set the touch response in the “Function Menu” (p. 21).




MODULATION (☉)

SUSTAIN



Modulation

Press and hold the [SUSTAIN] button to turn modulation effect on or off. When modulation is turned on, the “MODULATION” icon lights up. It will add vibrato effect to the notes you play.




Sustain

Press the [SUSTAIN] button to turn sustain effect on or off. When sustain is turned on, the “SUSTAIN” icon lights up. All the notes you play will have a longer sustain.


Note:

When using a pedal switch for sustain, it will have a stronger sustain effect than by using the [SUSTAIN] button.



DSP

The DSP simulates sounds in real environment. With the DSP effect, you can add ambiance and depth to your performance in a variety of ways. DSP is turned on by default. You can turn it on or off in the “Function Menu” (p. 21).




Transpose

This function will shift the pitch of the entire keyboard in semitone steps.

1. Press the [TRANPOSE] button. The LCD temporarily displays the transpose menu.
2. Use the [<]/[>] buttons to change the transpose value. Press the [<] and [>] buttons simultaneously to restore the default setting.
3. You can also press and hold the [TRANPOSE] button, then press a specific key to fast set the transpose value.

TRANPOSE



Key	Transpose value
C	0
C#	+1
D	+2
D#	+3
E	+4
F	+5
F#	-6
G	-5
G#	-4
A	-3
A#	-2
B	-1


Piano Mode

Press the [PIANO] button to enter or exit Piano mode.

In Piano mode, all parameters will be optimized for concert piano performance. You can play the accompaniment as in the other modes, but it plays only the rhythm part.

Note:

In Piano mode, Chord mode will be off automatically.



Auto Accompaniment

The auto accompaniment feature puts a full backing band at your fingertips. To use it, all you have to do is to play the chords with your left hand in the selected accompaniment style, and then the accompaniment will automatically play along, instantly following the chords you play. With auto accompaniment, even a solo performer can enjoy playing with the backing of an entire band or orchestra. This instrument features a variety of styles.

Try selecting some of the different styles and enjoy the auto accompaniment feature. Please refer to the "Style List" (p. 33).

Selecting Chord Modes

When Chord mode is off, you can press the [START/STOP] button to start playing the rhythm tracks.

When Chord mode is on, you can press the [START/STOP] button to start the rhythm tracks, then play a chord in the chord section to start all tracks.

In Chord mode, you can play back chords in the A.B.C mode and the WHOLE mode.


1. Press the [CHORD] button once to enter the "A.B.C." (Auto Bass Chord) mode.

The "A.B.C." icon on LCD lights up. The keyboard is split into two sections. Left hand section is the chord section. You can play single finger chords and multi-finger chords in the chord section.

2. Press the [CHORD] button again to enter the "WHOLE" mode.

The "WHOLE" icon on LCD lights up. You can play multi-finger chords over the entire keyboard.

3. Press the [CHORD] button again to turn off chord mode. The "WHOLE" icon turns off.




Playing Auto Accompaniment (Rhythm Track)

1. Press the [STYLE] button to enter Style mode.
The "STYLE" icon on LCD lights up. The LCD displays the current style name and number.
2. Use the numeric buttons or [<]/[>] buttons to select a style.
3. Press the [START/STOP] button to start playing the rhythm tracks.
4. Or you can press the [SYNC] button to turn on the Sync function. The beats on LCD blink. The Sync function puts the playback on standby. You can press any key on the keyboard to start the rhythm tracks.


Note:

You can play back the rhythm tracks while Chord mode is on or off.



Playing Auto Accompaniment (All Tracks)




1. Press the [CHORD] button to enter Chord mode.
2. Press the [SYNC] button to turn on the Sync function.
The beats on LCD blink. The Sync function puts the playback on standby. You can play a chord in the chord section to start playing all tracks.
3. Or you can press the [START/STOP] button to start the rhythm tracks. Then play a chord in the chord section to start all tracks.



Accompaniment Sections

There are various types of accompaniment sections. They are Intro, Main (A, B), Fill (A, B), and Ending.

1. Press the [STYLE] button.
2. Use the numeric buttons or [<]/[>] buttons to select a style.
3. Press the [CHORD] button to enter A.B.C. mode. The "A.B.C." icon on LCD lights up.
4. Press the [SYNC] button to enter Sync Start status.
5. Press the [FILL A]/[FILL B] button to select Main A or Main B.
6. Press the [INTRO/ENDING] button. The icon "A" or "B" on LCD will blink, indicating playback is on standby.
7. Now if you play a chord in the left hand chord section, the auto accompaniment will start. When the Intro section is finished, it will automatically lead into the Main section.
8. Press the [FILL A]/[FILL B] button. It will play fill A or fill B, then automatically lead to the corresponding Main section.
9. Press the [INTRO/ENDING] button. The icon "A" or "B" on LCD will blink. It will play the Ending section. When the Ending is finished, the playback will stop.



Note:

If you press the [FILL A]/[FILL B] button before the Ending is finished, it will play the selected fill then lead to the corresponding Main

Auto Accompaniment

Fade In / Out

Fade In

When style stops, press the [FADE] button to turn on the Fade In function. The “▲ FADE” icon on LCD light up.

Now if you start style playback, the “▲ FADE” icon on LCD blinks and the volume will increase from low to high.


Fade Out

When style is playing, you can press the [FADE] button to turn on the Fade Out function. The “FADE ▼” icon on LCD blinks.

The volume will decrease from high to low until the playback stops.

Note:

The default fade time is 10 seconds.




Accompaniment Volume

You can adjust the accompaniment volume to keep an appropriate balance between the accompaniment volume and the tone volume.

1. Press the [MIXER] button to enter the mixer menu.
2. Use the [<]/[>] buttons to select “Accomp”.
3. Press the [MIXER] button again to move the cursor to the volume level. The volume level will blink.
4. Use the [<]/[>] buttons to adjust the level. The range is OFF, 1~32.

Notes:

1. In the mixer menu, repeatedly press the [<] and [>] buttons simultaneously to mute or unmute the accomp volume. When the accomp volume is muted, the LCD displays “OFF Accomp”.
2. The accomp volume is not adjustable when playing demo, song or recorded song.



Auto Accompaniment

Chord Fingering

How the chords are played or indicated with your left hand (in the auto accompaniment section of the keyboard) is referred to as "fingering." There are 2 types of fingerings as described below.

Chord Basics

A chord, in music, is any harmonic set of three or more notes that is heard as if sounding simultaneously. The most frequently encountered chords are triads. A triad is a set of three notes that can be stacked in thirds. When stacked in thirds, the triad's members, from lowest pitched tone to highest, are called: the Root, the Third, and the Fifth.

Triad Type

There are following basic triad types:

Major Triad	A root with a major third added above and a perfect fifth will consist as a "Major Triad."
Minor Triad	A root with a minor third added above and a perfect fifth will consist as a "Minor Triad."
Augmented Triad	A root with a major third added above and an augmented fifth will consist as an "Augmented Triad."
Diminished Triad	A root with a minor third added above and a diminished fifth will consist as a "Diminished Triad."

Chord Inversion

We define this chord its root is not in the bass (i.e. the root is not the lowest note) as an inversion chord. When the root is in the bass, we call the chord: root-position chord. If we put the Third and Fifth in the root position, then it forms "Inversion," we call this chord "Inversion Chord." See the following major triad and its inverted chord.

Chord Name

The chord name contains two parts content: Chord root and Chord type.

Single Finger





Single finger type not only can detect single finger but also can detect multi finger. And the single finger makes it easily to play chords through only one, two or three keys. Including major, minor, seventh, and minor seventh chord. Refer to relevant picture on the right for details.

Multi-finger

Multi-finger allows you to play chords in normal fingering. Try playing the 32 chord types in C scale as listed on the right.

Note:

In WHOLE mode, the entire keyboard will only recognize chords played in normal fingering.



Cm

Chord Root Chord Type

C		★ Major Triad Only press the root note on the keyboard.
Cm		★ Minor Triad Press the root note and the nearest left black key simultaneously.
C7		★ Seventh chord Press the root note and the nearest left white key simultaneously.
Cm7		★ Minor seventh chord Press the root note and the nearest left white and black keys simultaneously.

0 C	1 C ₆	2 C _{M7}	3 C _{M7} (#11)	4 C _M (9)	5 C _{M7} (9)
6 C ₆ (9)	7 C _{aug}	8 C _m	9 C _{m6}	10 C _{m7}	11 C _{m7} (b5)
12 C _m (9)	13 C _{m7} (9)	14 C _{m7} (11)	15 C _{mM7}	16 C _{mM7} (9)	17 C _{dim}
18 C _{dim7}	19 C ₇	20 C _{7sus4}	21 C ₇ (b5)	22 C ₇ (9)	23 C ₇ (#11)
24 C ₇ (13)	25 C ₇ (b9)	26 C ₇ (b13)	27 C ₇ (#9)	28 C _{M7aug}	29 C _{7aug}
30 C _{sus4}	31 C 1+2+5	Notes: enclosed in parentheses ⊕ are optional; the chords could be recognized without them.			

Tempo

1. Press the TEMPO[-]/[+] button to change the tempo. The tempo value on LCD blinks. The range is 5~280.
2. Press and hold the TEMPO[-]/[+] button to fast change the tempo. Press the TEMPO [-] and [+] buttons simultaneously to restore the default tempo.



Notes:

1. When style stops, if you change the style, the tempo will be reset to the default tempo of the current style.
2. When style is playing, if “Tempo Remain” is turned on, when you change the style, the tempo will remain unchanged. If “Tempo Remain” is turned off, when you change the style, the tempo will be reset to the default tempo of the current style. You can turn the Tempo Remain on/off in the “Function Menu” (p. 21). Tempo Remain is turned off by default.

Metronome

The metronome provides a steady beat to help you practice at a preset tempo.

1. Press [METRONOME] button to turn the metronome on or off.
2. The default time signature is “4”. You can change it in the function menu. Press the [MENU] button to enter the function menu, then use the [<]/[>] buttons to select “Beat”. Then press the [MENU] button again to move the cursor to the beat value. Use the [<]/[>] buttons to change the beat.



Notes:

1. The metronome will respond in the next beat if it is turned on when style is playing.
2. If you turn on the metronome in Record mode, the metronome sound will not be recorded.

Arpeggiator


This function can automatically generate arpeggios. Simply play a chord with your left hand, the instrument will play a preset arpeggio pattern and produce beautiful melody.

Turn the Arpeggiator on or off

1. Press and hold the [TONE] button to turn on this function. The “ARP.” icon lights up.
2. Press and hold the [TONE] button again to turn off this function. The “ARP.” icon turns off.

Note:

Each tone has a preset arpeggio pattern. When you change the tone, arpeggio pattern and tempo will change.




Set the Split Point of Arpeggiator

When the arpeggiator is turned on, the keyboard will be split into two areas. Play chords in the left hand area, and melody in the right hand area. The default split point is the same as in the split function: F#3 (19).

Mixer

You can adjust the volume of different tracks in the mixer.

1. Press the [MIXER] button to enter the mixer menu. The current mixer parameter on LCD blinks.
2. Use [←]/[→] buttons to select a parameter.
3. Press the [MIXER] button again to move the cursor to the volume level. The volume level will blink.
4. Use [←]/[→] buttons to change the volume. You can press the [←] and [→] buttons simultaneously to restore the default volume.
5. Press the [STYLE], [TONE] or [SONG] button to exit the mixer menu.



Detailed parameters and their volume range:

Parameter	LCD Display	Range
Accomp volume	XXX Accomp	OFF, 1~32
Rhythm track volume	XXX Rhythm	OFF, 1~32
Bass track volume	XXX Bass	OFF, 1~32
Chord 1 track volume	XXX Chord1	OFF, 1~32
Chord 2 track volume	XXX Chord2	OFF, 1~32
Chord 3 track volume	XXX Chord3	OFF, 1~32
Upper 1 track volume	XXX Upper1	OFF, 1~32
Upper 2 track volume	XXX Upper2	OFF, 1~32
Lower track volume	XXX Lower	OFF, 1~32

Notes:

1. It will exit the mixer menu if there is no operation in 60 seconds.
2. Repeatedly press the [←] and [→] buttons simultaneously to mute the selected track (LCD displays “OFF”) or unmute it.


Quick Memory

This function allows you to save virtually all panel settings to a registration memory. You can instantly recall these settings by pressing a single button.

Note: The registered memory will be lost when the power turns off.

Registering the Panel Settings

1. The memory function is turned on by default when the power is turned on.
2. When this function is turned off, you can press the [QUICK MEMORY] button to turn this function on, the “MEMORY” icon on LCD lights up.
3. Press and hold the [QUICK MEMORY] button, then press one of the memory buttons [1] ~ [4] to save the panel settings to that button.
Note: It will overwrite the previous data saved in that button.
4. Parameters that can be saved to registration memory include:
Tone: main tone, dual tone, split tone, DSP effects, mixer settings.
Accompaniment: style, tempo, chord mode.
Function: touch response and some parameters in the function menu.



Recalling the Registered Settings

Press one of the memory buttons [1] ~ [4].

It will recall the settings saved in that button. This will reset related parameters on the control panel.

Notes:

1. By default, the four memory slots are empty when the power is turned on. If you press a memory button, the LCD will display “Empty” to indicate there’s no data.
2. Registration memory cannot be recalled when the O.T.S. function is in use.



One Touch Setting

When one touch setting function is in use, you can instantly recall the related tone settings to match the current style with a single touch of a button.

1. Press the [O.T.S.] button. The “O.T.S.” icon on LCD lights up.
If chord mode is turned off, the A.B.C. function will be turned on automatically.
If the WHOLE mode is turned on, it will stay in WHOLE mode when O.T.S. is engaged.
2. Press one of the O.T.S. buttons [1]–[4]. It will recall the tone and effect settings that match the selected style.
O.T.S. parameters include:
Main tone: volume, reverb level, octave.
Dual tone: volume, reverb level, octave.
Split tone: volume, reverb level, octave.
3. Press the [O.T.S.] button again to turn off this function.
It will automatically switch to registration memory. The “MEMORY” icon on LCD lights up.

Note:

Registration memory is not available when O.T.S. is in use.




Chord Dictionary


If you know the name of a chord but don't know how to play it, you can use the chord dictionary function.

1. Press the [CHORD DICT.] button to turn on this function. The LCD displays "DICT."
2. Use the key C4 and the keys above to assign the chord type. Use the key C6 and the keys above to assign the chord root. When the chord type and chord root are assigned, the LCD will display the chord name and chord notes.
3. When you play the chord correctly in the chord section, it will produce an applause sound.
4. Press the [CHORD DICT.] button again to exit this function.

Chord types and roots will be displayed in the Chord Reference mode as follows:



CHORD DICT.



Playing Songs



The instrument has a variety of songs. Please refer to the "Song List" (p. 35). Each song can be practiced in Lesson mode.

Listening to Songs

1. Press the [SONG] button to enter Song mode. Then press the [▶/■] button to start playing the song.
2. Use the numeric buttons or [←]/[→] buttons to select a song.
3. When song is playing, press the [▶/■] button to pause or continue the song playback.
4. Use the TEMPO[-]/[+] buttons to change the tempo of the current song.
5. When song stops, press these buttons to exit Song mode: [STYLE], [TONE], [DUAL],[SPLIT], [MENU], [MIXER], [1]-[4].

Note:

When song is playing, the [MENU] and [MIXER] buttons are not available.



Playing Songs

Lesson Mode

In Lesson mode, you can practice song in 3 lessons. They are Lesson 1, Lesson 2 and Lesson 3. Your practice will be evaluated when you finish a lesson.

1. You can enter Lesson mode from Song mode. When song stops, press the [LESSON] button to enter Lesson mode or select a lesson.
2. Press the [▶/■] button to start the lesson. The LCD will display the notes to play.
3. Press the [▶/■] button again to stop the lesson.

Lesson 1:

You will learn to play at the correct timing. As long as you play a key at the right time, the correct note will sound.

Lesson 2:

You will learn to play the correct notes. If you play a wrong note, the lesson will stop and wait, until you correctly play the note displayed on LCD.

Lesson 3:

You will learn to play the correct notes at the correct timing.

Grading:

When you finish a lesson, it will evaluate your practice and tell you the grades.


Level 1: OK.

Level 2: Good.

Level 3: Very Good.

Level 4: Excellent.


After grading, the song will play back again, so you can practice again.



Recording and Playing Back

You can record your performance and then play it back.

1. Press and hold the [▶/■] button to enter Record mode. The "RECORD" icon blinks. The beats on LCD blink.
2. Play the keyboard or press the [START/STOP] button to start recording. If you want to record accompaniment, turn on the Chord mode, then play chords in the chord section.
3. During recording, press and hold the [▶/■] button again to stop recording. The "RECORD" icon turns off.
4. During recording, press the [▶/■] button, it will stop recording and then play back the recording.
5. When in other modes (except Song mode), you can press the [▶/■] button to play back the recording. The "PLAY" icon lights up.
6. When the recording is playing, you can use the [▶/■] button to pause or continue the playback.
7. When the recording is playing, you can the [START/STOP] button to stop and exit playback. The "PLAY" icon turns off.



Note:

The recording data will be lost after power off.

Function Menu

1. Press the [MENU] button to enter the function menu. The current parameter on LCD blinks.
2. Use the [←]/[→] buttons to select a parameter.
3. Press the [MENU] button again to move the cursor to select the value.
4. Use the [←]/[→] buttons to change the value.
5. Pressing the [←] and [→] buttons simultaneously to restore the default value of the current parameter.
6. Press the [STYLE], [TONE] or [SONG] button to exit the function menu.



Detailed parameters and their ranges:

Parameter	LCD Display	Range	Default
Tune	XXX Tune	-50 ~ 50	0
Octave	XXX Octave	-2 ~ 2	0
Split Point	XXX SplitPt	1 ~ 61	19
Beat Type	XXX Beat	0, 2 ~ 9	4
Touch Response	XXX Touch	OFF, 1~3	2
Modulation	XXX Modul	On, OFF	OFF
DSP	XXX Dsp	On, OFF	On
Reverb Type	XXX RevType	1 ~ 10	4
Reverb Level	XXX Rev Lev	0 ~ 32	13
Chorus Type	XXX ChrType	1 ~ 8	3
Chorus Level	XXX Chr Lev	0 ~ 32	0
Tempo Remain	XXX TempRmn	On, OFF	OFF
Auto Off	XXX AutoOff	OFF, 30, 60	30

Note:


1. It will exit the function menu if there is no operation in 60 seconds.
2. The function menu edited parameters will be lost when the power turns off.

Tune

This function adjusts the pitch of the keyboard up or down in a 2-cent increment.

1. In the function menu, press the [←]/[→] buttons to select the tune menu. The LCD displays “Tune”.
2. Press the [MENU] button to move the cursor to the value.
3. Use the [←]/[→] buttons to change the value. Pressing the [←] and [→] buttons at the same time will restore the default value.


Note: This setting applies to both accompaniment and tone.



Octave

This function shifts the pitch of the keyboard up or down by one octave.

1. In the function menu, press the [←]/[→] buttons to select the octave menu. The LCD displays “Octave”.
2. Press the [MENU] button to move the cursor to the value.
3. Use the [←]/[→] buttons to change the value. Pressing the [←] and [→] buttons at the same time will restore the default value.




Function Menu

Split Point

This function sets the split point for the Split mode and the Chord mode.


1. In the function menu, press the [←]/[→] buttons to select the split point menu. The LCD displays “SplitPt”.
2. Press the [MENU] button to move the cursor to the value.
3. Use the [←]/[→] buttons to change the value. Pressing the [←] and [→] buttons at the same time will restore the default value.



Beat Type

This function sets the metronome beat type.

1. In the function menu, press the [←]/[→] buttons to select the beat menu. The LCD displays “Beat”.
2. Press the [MENU] button to move the cursor to the value.
3. Use the [←]/[→] buttons to change the value. Pressing the [←] and [→] buttons at the same time will restore the default value.




Touch Response

This function sets the velocity response of the keyboard.

1. In the function menu, press the [←]/[→] buttons to select the touch response menu. The LCD displays “Touch”.
2. Press the [MENU] button to move the cursor to the value.
3. Use the [←]/[→] buttons to change the value. Pressing the [←] and [→] buttons at the same time will restore the default value.

No.	Touch Response
OFF	fixed
1	Heavy
2	Medium
3	Light




Modulation

This function turns the modulation effect on or off.

1. In the function menu, press the [←]/[→] buttons to select the modulation menu. The LCD displays “Modul”.
2. Press the [MENU] button to move the cursor to the setting.
3. Use the [←]/[→] buttons to change the setting. Pressing the [←] and [→] buttons at the same time will restore the default setting.

Note: Modulation is not available for percussive tones.




DSP

This function turns the DSP effect on or off.

1. In the function menu, press the [←]/[→] buttons to select the DSP menu. The LCD displays “Dsp”.
2. Press the [MENU] button to move the cursor to the setting.
3. Use the [←]/[→] buttons to change the setting. Pressing the [←] and [→] buttons at the same time will restore the default setting.

Note: When DSP is off, following Reverb and Chorus effects turn off.




Function Menu

Reverb Type

This function selects the reverb type.


1. In the function menu, press the [←]/[→] buttons to select the reverb type menu. The LCD displays “RevType”.
2. Press the [MENU] button to move the cursor to the value.
3. Use the [←]/[→] buttons to change the value. Pressing the [←] and [→] buttons at the same time will restore the default value.



Reverb Level

This function adjusts the reverb level.


1. In the function menu, press the [←]/[→] buttons to select the reverb level menu. The LCD displays “RevLev”.
2. Press the [MENU] button to move the cursor to the value.
3. Use the [←]/[→] buttons to change the value. Pressing the [←] and [→] buttons at the same time will restore the default value.



Chorus Type

This function selects the chorus type.


1. In the function menu, press the [←]/[→] buttons to select the chorus type menu. The LCD displays “ChrType”.
2. Press the [MENU] button to move the cursor to the value.
3. Use the [←]/[→] buttons to change the value. Pressing the [←] and [→] buttons at the same time will restore the default value.



Chorus Level

This function adjusts the chorus level.


1. In the function menu, press the [←]/[→] buttons to select the chorus level menu. The LCD displays “ChrLev”.
2. Press the [MENU] button to move the cursor to the value.
3. Use the [←]/[→] buttons to change the value. Pressing the [←] and [→] buttons at the same time will restore the default value.



Tempo Remain

When this function is turned on, the tempo will remain unchanged when changing style during style playback.


1. In the function menu, press the [←]/[→] buttons to select the tempo remain menu. The LCD displays “TempoRmn”.
2. Press the [MENU] button to move the cursor to the setting.
3. Use the [←]/[→] buttons to change the setting. Pressing the [←] and [→] buttons at the same time will restore the default setting.



Auto Off

The instrument will automatically shut down after 30 minutes of inactivity. Selecting “OFF” will disable this function.

1. In the function menu, press the [←]/[→] buttons to select the auto off menu. The LCD displays “AutoOFF”.
2. Press the [MENU] button to move the cursor to the value.
3. Use the [←]/[→] buttons to change the value. Pressing the [←] and [→] buttons at the same time will restore the default value.



MIDI

MIDI (short for Musical Instrument Digital Interface) allows a wide variety of electronic musical instruments, computers and other related devices to connect and communicate with one another.

MIDI carries event messages that specify notation, pitch and velocity, control signals for parameters such as volume, vibrato, audio panning, and program change information to change the tone selections.

The instrument can output the real-time playback information via MIDI messages and control external MIDI devices. The instrument can also accept incoming MIDI messages and generate sound accordingly.

Note:

This instrument has a USB computer jack (p. 7), which can be connected to a computer as a MIDI input or MIDI output. This can not be connected with another instrument, unless the instrument has a USB host terminal.

The main application of MIDI

1. Used as a tone generator.

This instrument can receive MIDI data from computer, and execute MIDI controls to change channels, change tones, add effect and make sound and so on. Refer to MIDI Implementation Chart for more MIDI controls.


2. Used as a MIDI Keyboard

When you play the keyboard, change the tones or turn the DSP on/off, the instrument will send MIDI data to the computer, which will be saved as records (It only records your keyboard performance when playing along with accompaniment.) You can edit the records on the computer, such as changing the channels or tones, adding DSP effects. Then play back the records with the instrument or other sound source (such as a sound card). You can play the keyboard along with the playback. Refer to MIDI Implementation Chart for more MIDI controls.

Connecting to a MIDI Software on Computer

To use the USB computer jack (p. 7) of the instrument, you may need to configure the software on computer. For example, setting Digital Audio Workstation (DAW) software under WINDOWS10 operating system:

1. Use a standard USB cable to connect the instrument to computer. Make sure the instrument is turned on.
2. Open Digital Audio Workstation (DAW) software on computer.
3. The software will automatically recognize the E-X10 USB DEVICE either as the MIDI Input or as the MIDI Output. For more configuration information, please refer to the HELP of the software.
4. You can follow the above operations when using other similar MIDI software.



Troubleshooting

Problem	Possible Cause and Solution
The speakers produce a pop sound whenever the power is turned on or off.	This is normal and does not indicate a malfunction.
Speakers do not produce sound when the keyboard is played.	<ol style="list-style-type: none"> 1. Check if the master volume is set too low. 2. Check if the Upper1/Upper2/Lower sound volume is set too low in the mixer menu. 3. Check if headphones are plugged into the PHONES jack.
The speakers produce noise when a mobile phone is put near them.	Using a mobile phone in close proximity to the instrument may produce interference. To prevent this, turn off the mobile phone or use it farther away from the instrument.
The auto accompaniment does not play back even when sync start is engaged and a key is pressed.	You may be playing keys in the right hand range of the keyboard. To start the accompaniment with sync start, make sure to play keys in the left~hand range.
Certain notes seem to be in the wrong pitch.	Make sure that the tune value is set to 0 in the function menu.
When connecting to computer, the instrument cannot be recognized.	Check if the USB cable is firmly connected. Try connecting another USB port on the computer. This instrument is plug and play and should work without installing a driver.
The pedal does not respond.	Check if the pedal cable is firmly connected.
When using a pedal switch , it doesn't sustain the notes when the pedal is pressed, but it sustain the notes when the pedal is released.	The polarity of different pedals may vary. If the connected pedal switch works in reversed behavior, please plug the pedal to the PEDAL jack before turning the power on.
It shuts down after a period of time.	The Auto Off function will turn off the instrument after a preset period of time when the instrument is not in use. You can disable this function in the function menu.

Specifications

Keyboard	61 keys with touch response	
Display	Multi-functional LCD	
Max polyphony	64	
Tone	610 presets	
Style	207 presets	
Demo song	140	
Song	140	
Layer	L, R1, R2	
Split	Yes	
Style control	Start / Stop Sync Start Intro Main (A, B) Fill (A, B) Ending Chord mode Fade in / out Accomp volume	
Chord type	32	
Reverb	10 types, 33 levels	
Chorus	8 types, 33 levels	
Effects	DSP effects, Modulation	
Mixer	Yes	
Sequencer	1 user song	
Quick Memory	4 memories	
O.T.S.	Yes	
Pitch adjustment	Transpose, Octave, Tune	
Metronome	Yes	
Tempo	5 ~ 280	
Other control	Touch response, Arpeggiator	
Connector	USB	USB MIDI
	Headphone	1 standard stereo
	Output	Yes (Phones jack)
	Microphone	Yes
	Pedal	Sustain pedal
	Aux In	Yes
Amplifier	2 x 2.5 watt	
Speaker	2 x 12 cm	
Power	DC 12V, 2000mA or 6 x AA Batteries	
Battery life for Continuous use	Alkaline batteries (AA, LR6): Approximately 3 hours * This figure will vary depending on the actual conditions of use.	
Dimension	947x317x100 mm	
Weight	3.9 kg	

- This document explains the specifications of the product at the time that the document was issued. For the latest information, refer to the Roland website.
- All specifications are subject to change without notice.

Tone List

NO.	English Name	LCD Name
PIANO		
1	Grand Piano	GrandPno
2	Ballad Piano	BalladP
3	Mellow Piano	MellowP
4	Bright Piano	BrightP
5	Acoustic Piano	AcPiano
6	Acoustic Piano (dark) 1	AcPnoD1
7	Acoustic Piano (dark) 2	AcPnoD2
8	Octave Piano 1	OctPno1
9	Octave Piano 2	OctPno2
10	Piano & Choir	Pno&Cho
11	Acoustic Piano (wide)	AcPianoW
12	Analog E.Piano 1	AnEPno1
13	Analog E.Piano 2	AnEPno2
14	Analog E.Piano Wah	AnPnoWah
15	Bright Acoustic Piano 1	AcPnoB1
16	Bright Acoustic Piano 2	AcPnoB2
17	Stereo Bright Piano	AcPnoBS
18	Detuned Piano	DetunPno
19	Chorus Piano 1	ChoPno1
20	Chorus Piano 2	ChoPno2
21	Bright Piano 1 / W	AcPnoB1W
22	Bright Piano 2 / W	AcPnoB2W
23	Piano & Vibraphone	Pno&Vib
24	Electric Grand Piano	E.PianoG
25	Electric Grand Piano / W	E.PianoW
26	Stereo Synth E.Piano 1	StSyEIPn1
27	Stereo Synth E.Piano 2	StSyEPn2
28	Honky-Tonk Piano	HnkyTonk
29	Honky-Tonk Dark	HnkTonkD
30	Honky-Tonk / W	HnkyTkW
31	Honky-Tonk 2 / W	HnkyTkW2
32	E.Piano 1	E.Piano 1
33	Stereo E.Piano	E.PianoS
34	50's E.Piano	50'sEP
35	E.Piano 1 / W	EPianoW1
36	E.Piano 2 / W	EPianoW2
37	E.Piano 3 / W	EPianoW3
38	E.Piano 4 / W	EPianoW4
39	E.Piano 2	E.Piano2
40	E.Piano 3	E.Piano3
41	Funk EP	FunkEP
42	Detuned E.P. 1	DetunEP1
43	Detuned E.P. 2	DetunEP2
44	Harpsichord 1	Harpsi1
45	Harpsichord 1 / W	HarpsiW1
46	Harpsichord 2 / W	HarpsiW2
47	Harpsichord Octave 1	HarpsiO1
48	Harpsichord Octave 2	HarpsiO2
49	Harpsichord Off	HarpsiOf
50	Digital E.Piano 1	DigiEP1
51	Digital E.Piano 2	DigiEP2
52	Clavichord 1	Clavi1
53	Clavichord 2	Clavi2
54	Stereo Clavichord	ClaviS
55	Clavichord / W	ClaviW
56	Clavichord Wah	ClaviWa
57	Synth Clav	SynClav

CHROMATIC PERCUSSION		
58	Celesta 1	Celesta1
59	Celesta 2	Celesta2
60	Dark Celesta 1	CelestD1
61	Dark Celesta 2	CelestD2
62	Celesta & Sine	Cele&Sin
63	Reecho Bell 1	ReBell1
64	Reecho Bell 2	ReBell2
65	Celesta & Music Box	Cel&Mbox
66	Glockenspiel	Glocken
67	Glockenspiel & Sine	Glkn&Sin
68	Children's Song	ChilSong
69	Analog Bell	AnaBell
70	Stereo Analog Bell	StAnaBel
71	Music Box	MusicBox
72	Vibraphone	Vibra
73	Vibraphone / W	VibraW
74	Vibraphone & Bell	Vibr&Bel
75	Vibraphone & Harpsichord	Vibr&Hrp
76	Marimba 1	Marimba1
77	Marimba 2	Marimba2
78	Marimba 1 / W	MarimbW1
79	Marimba 2 / W	MarimbW2
80	Sine Marimba	Marm&Sin
81	Stereo Marimba	MarimbaS
82	Marimba & Vibraphone	Marm&Vib
83	Wood Drum	WoodDrum
84	Rotating	Rotating
85	Dual Attack	DualAtta
86	Stereo TRI	StTRI
87	Xylophone 1	Xylopho1
88	Xylophone 2	Xylopho2
89	Tubular Bells 1	TubuBel1
90	Tubular Bells 2	TubuBel2
91	Tubular Bells 3	TubuBel3
92	Rotate Octave	RotateOc
93	Synth Organ Staccato 1	SyOrSta1
94	Synth Organ Staccato 2	SyOrSta2
95	Dulcimer 1	Dulcimer1
96	Dulcimer 2	Dulcimer2
ORGAN		
97	Drawbar Organ	DrawOrg
98	Stereo Drawbar Organ	DrawOrgS
99	Soft Stereo Drawbar Organ	DrawOgSf
100	Mellow Drawbar Organ	MellDOrg
101	Bright Drawbar Organ	DrawOrgB
102	Percussive Organ	PercOrgn
103	Percussive Organ Detuned	DePerOrg
104	Rock Organ 1	RockOrgn1
105	Rock Organ 2	RokOrgn2
106	Church Organ	ChurOrgn
107	Detuned Church Organ	DeChuOrg
108	Octave Church Organ 1	ChrOrgO1
109	Octave Church Organ 2	ChrOrgO2
110	Finale 1	Finale1
111	Finale 2	Finale2
112	Digital Organ	DigiOrg
113	Analog Organ 1	AnaOrg1
114	Analog Organ 2	AnaOrg2

Tone List

115	Reed Organ 1	ReedOrg1
116	Reed Organ 2	ReedOrg2
117	Stereo Reed Organ	ReedOrgS
118	Accordion 1	Acordin1
119	Accordion 2	Acordin2
120	Stereo Accordion	AcordinS
121	Harmonica	Harmnica
122	Dark Harmonica	HarmnicD
123	Tango Accordion	TangoAcid
124	Dark Tango Accordion	TangAcidD
GUITAR		
125	Nylon Guitar	NylonGtr
126	Chorus Nylon Guitar	NylonGtC
127	Stereo Nylon Guitar 1	NyInGtS1
128	Stereo Nylon Guitar 2	NyInGtS2
129	Acoustic Guitar (steel) 1	SteelGt1
130	Acoustic Guitar (steel) 2	SteelGt2
131	12 String Guitar	12StrGtr
132	Detuned Steel Guitar	DetStlGt
133	Jazz. Guitar	JazzGtr
134	Clean Guitar 1	CleanGt1
135	Clean Guitar 2	CleanGt2
136	Clean Guitar 3	CleanGt3
137	Stereo Clean Guitar	CleanGtS
138	Soft Clean Guitar	CInGtSof
139	Chord Clean Guitar	CInGtCho
140	Electric Guitar (muted) 1	MutedGt1
141	Muted Guitar 2	MutedGt2
142	Muted Guitar 3	MutedGt3
143	Stereo Muted Guitar	MutedGtS
144	Chord Muted Guitar	MutGtCho
145	Overdrive Guitar	Ovrdrive
146	Dance Lead	DancLead
147	Distortion Guitar 1	DistGtr1
148	Distortion Guitar 2	DistGtr2
149	Analog Distortion Guitar	AnDistGt
150	5Th Distortion 1	5ThDist1
151	5Th Distortion 2	5ThDist2
152	Analog Distortion	AnaDist
153	Analog Distortion 2	AnaDist2
154	Analog Distortion Wah	AnDisWah
155	Analog Distortion Wah 2	AnDisWa2
156	Guitar Harmonics	GtrHarmo
BASS		
157	Acoustic Bass 1	AcoBass1
158	Acoustic Bass 2	AcoBass2
159	Acoustic Bass Detuned	DetAcoBs
160	Velocity Crossfade Bass	VelCroBs
161	Jazz Style	JazzSty
162	A.Bass & Mute G.T.	ABs&MtGT
163	Finger Bass 1	FngBass1
164	Finger Bass 2	FngBass2
165	Finger Bass 3	FngBass3
166	Finger Bass 4	FngBass4
167	Dark Finger Bass	FngrBsD
168	Detuned Finger Bass	DetFngBs
169	Velocity Bass	VelBass
170	Bass & Distortion Guitar	Bs&DisGt
171	Pick Bass 1	PickBs1
172	Pick Bass 2	PickBs2

173	Pick Bass 3	PickBs3
174	Mute Pick Bass	PickBsM
175	Pick & Finger Bass	Pk&FgBs
176	Pick Bass & Clean Guitar	PBs&ClGt
177	Detuned Pick Bass	DetPkBs
178	Fretless Bass 1	Fretles1
179	Fretless Bass 2	Fretles2
180	Fretless Bass 3	Fretles3
181	Slap Bass 1	SlapBas1
182	Slap Bass 2	SlapBas2
183	Slap Bass 3	SlapBas3
184	Slap Bass 4	SlapBas4
185	Slap Bass 5	SlapBas5
186	Synth Bass	SynBass
187	Synth Bass 2	SynBass2
188	Synth Bass 3	SynBass3
189	Synth Bass 4	SynBass4
190	Synth Bass 5	SynBass5
STRINGS & ORCHESTRAL		
191	Violin 1	Violin1
192	Violin 2	Violin2
193	2 Violin	2Violin
194	Viola 1	Viola1
195	Viola 2	Viola2
196	2 Viola	2Viola
197	Cello 1	Cello1
198	Cello 2	Cello2
199	2 Cello	2Cello
200	Contrabass 1	Contrbs1
201	Contrabass 2	Contrbs2
202	Tremolo Strings 1	TremStr1
203	Tremolo Strings 2	TremStr2
204	Tremolo Strings 3	TremStr3
205	Pizzicato Strings 1	PizzStr1
206	Pizzicato Strings 2	PizzStr2
207	Pizzicato Strings 3	PizzStr3
208	Orchestral Harp 1	Harp1
209	Orchestral Harp 2	Harp2
210	Orchestral Harp 3	Harp3
211	Stereo Harp	HarpS
212	Timpani 1	Timpani1
213	Timpani 2	Timpani2
214	Timpani 3	Timpani3
215	Strings Ensemble 1	Strings1
216	Strings Ensemble 2	Strings2
217	Strings Ensemble 3	Strings3
218	Boiling Strings	Boiling
219	Stereo Strings 1	StringS1
220	Stereo Strings 2	StringS2
221	Synth Strings 1	SynStrs1
222	Synth Strings 2	SynStrs2
223	Synth Strings 3	SynStrs3
224	Stereo Synth Strings 1	SynStrS
225	Stereo Synth Strings 2	SynStrS2
226	Analog Orchestra	AnaOrch
227	Analog String 1	AnaStr1
228	Analog String 2	AnaStr2
229	Slow Strings 1	SlowStr1
230	Slow Strings 2	SlowStr2
231	Choir Aahs 1	ChoirAah1

Tone List

232	Choir Aahs 2	ChoirAh2
233	Dark Aahs 1	ChoAhD1
234	Dark Aahs 2	ChoAhD2
235	Stereo Aahs 1	ChoAhS1
236	Stereo Aahs 2	ChoAhS2
237	Mellow Choir Aahs	ChoAhMel
238	Aahs & SynStr	Ah&SyStr
239	Big Aahs	BigAahs
240	Analog Sound 1	AnSound1
241	Analog Sound 2	AnSound2
242	Analog Sound 3	AnSound3
243	Voice Ooh	VoiceOoh
244	Synth Voice 1	SynVoic1
245	Synth Voice 2	SynVoic2
246	Stereo Synth Voice	SynVoicS
247	Synth Voice 3	SynVoic2
248	Homesick	Homesick
249	Child Interest	Interest
250	Child Interest 2	Intrest2
251	Mechanical Voice 1	MechaVo1
252	Mechanical Voice 2	MechaVo2
253	Child Interest Wah	InterWah
254	Orchestra Hit	OrchHit
255	Orchestra Hit Stereo	OrchHitS
256	Orchestra Hit Octave	HitOctO
BRASS		
257	Trumpet	Trumpet
258	Trumpet 2	Trumpet2
259	Dark Trumpet	TrumpetD
260	Dark Trumpet 2	TrmpetD2
261	Wah Trumpet	TrumpetW
262	Trombone	Trmbone
263	Trombone 2	Trmbone2
264	Tuba	Tuba
265	Tuba 2	Tuba2
266	Muted Trumpet	MuteTrp
267	Muted Trumpet 2	MuteTrp2
268	Horn	Horn
269	Horn 2	Horn2
270	Horn 3	Horn3
271	Stereo Synth Brass	StSyBras
272	5th Horn	5thHorn
273	Brass Ensemble	Brass
274	Majestic Unison	Unison
275	Synth Brass	SynBras
276	Synth Brass 2	SynBras2
277	Synth Brass 3	SynBras3
278	Synth Brass 4	SynBras4
279	Synth Brass 5	SynBras5
280	Sharp Bras	SharpBra
281	Analog Brass	AnaBrass
282	Analog Brass 2	AnaBras2
283	Dynamics Analog Brass	DyAnaBra
284	Octave Synth Brass	SynBrasO
REED		
285	Soprano Sax	SprnSax
286	Soprano Sax 2	SprnSax2
287	Alto Sax	AltoSax
288	Alto Sax 2	AltoSax2

289	Tenor sax	TenoSax
290	Tenor sax 2	TenoSax2
291	Baritone Sax	BariSax
292	Baritone Sax 2	BariSax2
293	Oboe	Oboe
294	Oboe 2	Oboe2
295	Sweet Oboe	SwetOboe
296	English Horn	EngHorn
297	English Horn 2	EngHorn2
298	Bassoon	Bassoon
299	Bassoon 2	Bassoon2
300	Clarinet	Clarine
301	Clarinet 2	Clarine2
PIPE		
302	Piccolo	Piccolo
303	Piccolo 2	Piccolo2
304	Flute	Flute
305	Flute 2	Flute2
306	Recorder	Recordr
307	Recorder 2	Recordr2
308	Pan Flute	PanFlut
309	Pan Flute 2	PanFlut2
310	Blown Bottle	Bottle
311	Blown Bottle 2	Bottle2
312	Shakuhachi	Shakchi
313	Shakuhachi 2	Shakchi2
314	Whistle	Whistle
315	Whistle 2	Whistle2
316	Ocarina	Ocarina
317	Ocarina 2	Ocarina2
SYNTH LEAD		
318	Square Lead	SquarLd
319	Square Lead 2	SquarLd2
320	Square Lead 3	SquarLd3
321	Analog Lead	AnaLead
322	Lead Sine	SineLead
323	Lead Sine 2	SinLead2
324	Analog Electric	AnaElect
325	Slow Square Lead	SlowLead
326	Analog Classic Lead	AnClasLd
327	Thick Square	ThickSq
328	Quint	Quint
329	Sine Solo	SineSolo
330	Pulse Lead	PulseLd
331	Pulse Lead 2	PulseLd2
332	Mellow Wind	Wind
333	80's Digital	80'sDig
334	Classic TRI	ClassTRI
335	Stereo Analog Wind	StAnWind
336	Stereo Analog Wind 2	StAnWid2
337	Sawtooth Lead	SawLead
338	Sawtooth Lead 2	SawLead2
339	Sawtooth Lead 3	SawLead3
340	Stereo Sawtooth	SawLdS
341	Stereo Sawtooth 2	SawLdS2
342	Stereo Sawtooth 3	SawLdS3
343	Electronic Lead	ElecLead
344	Psychedelic	Psyched
345	80's Synth	80'sSyn

Tone List

346	5Th Analog	5ThAna
347	5Th Analog 2	5ThAna2
348	Vitality	Vitality
349	5th Sawtooth	5thSaw
350	5th Sawtooth 2	5thSaw2
351	Comedy	Comedy
352	Comedy 2	Comedy2
353	Warm Sawtooth	WarmSaw
354	80's Sawtooth	80'sSaw
355	Wind Chimes Lead	WChimeLd
356	5Th Digital Age	5ThDigAg
357	5Th Digital Age 2	5ThDgAg2
358	5Th Square	5ThSqu
359	5Th Square 2	5ThSqu2
360	Stereo Pulse	StPulse
361	Stereo Pulse 2	StPulse2
362	Analog Signal	AnSignal
363	Analog Signal 2	AnSignl2
364	Stereo Electronic Lead	StElecLd
365	Stereo Electronic Lead 2	StEleLd2
366	Stereo Electronic Lead 3	StEleLd3
367	Stereo Electronic Lead 4	StEleLd4
368	Calliope Lead	CalipLd
369	Calliope Lead 2	CalipLd2
370	Calliope Lead 3	CalipLd3
371	Grand	Grand
372	Grand 2	Grand2
373	Octave Pad	OctPad
374	Classic Lead	ClassLD
375	Sawtooth Wah	SawWah
376	Chiff Lead	ChiffLd
377	Chiff Lead 2	ChiffLd2
378	Chiff Lead 3	ChiffLd3
379	Charang Lead	CharnLd
380	Charang Lead 2	CharnLd2
381	Fruity Lead	FruityLd
382	Fruity Lead 2	FruityLd2
383	Voice Lead	VoiceLd
384	Voice Lead 2	VoiceLd2
385	Robot	Robot
386	Robot 2	Robot2
387	Modulation Distortion	ModDist
388	Modulation Distortion 2	ModDist2
389	Control	Control
390	Vague Vocals	VagueVo
391	Singl Synth	SinglSyn
392	Analog Filter	AnaFilt
393	Analog Voice	AnaVo
394	Analog Voice 2	AnaVo2
395	Fifths Lead	FifthsLd
396	Retro Machine 1	Retro1
397	Retro Machine 2	Retro2
398	Bass & Lead	Bs&Lead
399	Bass & Lead 2	Bs&Lead2
400	Bass & Lead 3	Bs&Lead3
401	Classic Synth	ClassSyn
402	Classic Synth 2	ClassSy2
403	Classic Synth 3	ClassSy3
404	Electron Impac	EleImpac

405	Elastic Across	Across
406	Single Sawtooth	SinglSaw
407	Analog Wind	AnaWind
408	Electron Saw	EleSaw
409	Boring Sine	BorSine
410	Steel Wire	SteelWir
411	Steel Wire 2	SteelWr2
412	Analog Pulse	AnaPulse
413	Happiness	Happines
414	Happiness 2	Happine2
415	Happiness 3	Happine3
416	Deformation Pulse	DefPulse
SYNTH PAD		
417	New Age Pad	NewAgPd
418	New Age Pad 2	NewAgPd2
419	New Age Pad 3	NewAgPd3
420	Rise	Rise
421	Praise	Praise
422	Intangible	Intangi
423	Warm Day	WarmDay
424	Warm Day 2	WarmDay2
425	Warm Day 3	WarmDay3
426	Dunhuang	Dunhuang
427	Free Space	FreeSpa
428	Plump Sawtooth	PlumpSaw
429	Square Wah	SquaWah
430	Double Pulse	DoubPul
431	Comedy Wah	ComeWah
432	Phase Shift	PhaShift
433	Phase Shift 2	PhaShit2
434	Warm Pad	WarmPad
435	Warm Pad 2	WarmPad2
436	Overture	Overture
437	Verve	Verve
438	Fulness Pad	FulnesPd
439	Overture Wah	OvertWah
440	Digital Age	DigitAge
441	Analog Pad	AnaPad
442	Analog Pad 2	AnaPad2
443	Analog Pad 3	AnaPad3
444	Analog Pad 4	AnaPad4
445	Analog Pad 5	AnaPad5
446	Analog Wah	AnaWah
447	Sharp	Sharp
448	Warm Pulse	WarmPul
449	Warm Pulse 2	WarmPul2
450	Happiness Pad	HappiPd
451	Sawtooth Pad	SawPad
452	Sawtooth Pad 2	SawPad2
453	Poly Synth Pad	PlySyPd
454	Poly Synth Pad 2	PlySyPd2
455	Poly Synth Pad 3	PlySyPd3
456	Modulation Distortion Wah	ModDiWah
457	Choir Pad	ChoPad
458	Choir Pad 2	ChoPad2
459	Plush Pad	PlushPad
460	Dawn Wah	DawnWah
461	Chorus Pad Wah	ChoPdWah
462	Electric Pad	ElecPad

Tone List

463	5Th PAD	5ThPad
464	Bowed Pad	BowdPad
465	Bowed Pad 2	BowdPad2
466	Bowed Pad 3	BowdPad3
467	Metallic Pad	MetalPad
468	Dream	Dream
469	Dream 2	Dream2
470	Dream 3	Dream3
471	Pray	Pray
472	Digital Pad	DigiPad
473	Organ Pad Wah	OrganWah
474	Pipe Organ Pad	PipOrPd
475	Scene Pad	ScenePad
476	Halo Pad	HaloPad
477	Halo Pad 2	HaloPad2
478	Background	Backgrd
479	Background 2	Backgrd2
480	Background 3	Backgrd3
481	Background 4	Backgrd4
482	Sweep Pad	SweepPad
483	Space Pad	SpacePad
484	Digital Wah	DigiWah
485	Warm Wah	WarmWah
486	Pulse Wah	PulseWah
487	Digital Distortion Wah	DiDisWah
488	Pulse	Pulse
489	Pulse 2	Pulse2
490	Pulse 3	Pulse3
SYNTH SFX		
491	Rain	Rain
492	Mysterious	Mysterio
493	Clusters of Stars	Stars
494	Additive Synthesis	AddSynth
495	Want To Go	Wanttogo
496	Additive Synth Wah	AddWah
497	Soundtrack	Soundtrk
498	Wind Chimes	WChime
499	Far Away	FarAway
500	Crystal	Crystal
501	Crystal 2	Crystal2
502	Crystal 3	Crystal3
503	Drops Of Water	Water
504	Game	Game
505	Game 2	Game2
506	Fly Into Space	Fly
507	Little Funny	Funny
508	Funny Hammer	FunnyHam
509	Surface Of The Water	Surface
510	Water Drop	WaterWah
511	Atmosphere	Atmosphr
512	Clouds	Clouds
513	Clouds 2	Clouds2
514	Brightness	Bright
515	Brightness 2	Bright2
516	Life	Life
517	Life 2	Life2
518	Fresh	Fresh
519	Fresh 2	Fresh2
520	Goblins	Goblins

521	Fantasy	Fantasy
522	Space Trojan	SpaceTro
523	Ceremony	Ceremony
524	Phonism	Phonism
525	Phonism 2	Phonism2
526	Echoes	Echoes
527	Echoes 2	Echoes2
528	Empty	Empty
529	Empty 2	Empty2
530	Deformation	Deformat
531	Deformation 2	Deforma2
532	Sci-Fi	Sci-Fi
533	Sci-Fi 2	Sci-Fi2
534	WindBells	WindBell
535	WindBells 2	WindBel2
536	Artistic	Artistic
537	Artistic 2	Artisti2
538	Artistic 3	Artisti3
539	Artistic 4	Artisti4
540	Artistic 5	Artisti5
541	Digital Effect	DigitaEf
542	Abyss	Abyss
543	Abyss 2	Abyss2
544	Abyss 3	Abyss3
545	Spectrum	Spectrum
546	Spectrum 2	Spectru2
547	Spectrum 3	Spectru3
WORLD		
548	Harmonium 1	Hrmnium1
549	Harmonium 2	Hrmnium2
550	Sitar 1	Sitar1
551	Sitar 2	Sitar2
552	Sitar 3	Sitar3
553	Detuned Sitar	DetSitar
554	Tanpura	Tanpura
555	Santur 1	Santur1
556	Santur 2	Santur2
557	Santur 3	Santur3
558	Cavaquinho	Cavaquinho
559	Banjo	Banjo
560	Banjo 2	Banjo2
561	Shamisen	Shamisl
562	Shamisen 2	Shamisl2
563	Shamisen 3	Shamisl3
564	Koto	Koto
565	Koto 2	Koto2
566	Koto 3	Koto3
567	Kalimba	Kalimba
568	Kalimba 2	Kalimba2
569	Kalimba 3	Kalimba3
570	Bagpipe	Bagpipe
571	Bagpipe 2	Bagpipe2
572	Fiddle	Fiddle
573	Fiddle 2	Fiddle2
574	Shania	Shania
575	Shania 2	Shania2
576	Pipa	Pipa
577	ErHu	ErHu
578	GuZheng	GuZheng

Tone List

579	HuLuSi	HuLuSi
580	Xun	Xun
581	YangQin	YangQin
PERCUSSION		
582	Tinkle Bell	TnklBell
583	Agogo	Agogo
584	Steel Drums	StelDrum
585	Bass Drum	BassDrum
586	Wood Block	WoodBlok
587	Snare	Snare
588	Taiko Drum	TaikoDrm
589	Melodic Tom	MelodTom
590	Synth Drum	SynDrum
591	Dynamics jump	Dynjump
592	Reverse Cymbal	RevCymbbl
SFX		
593	Guitar Fret Noise	FretNoiz
594	Breath Noise	BrthNoiz
595	Seashore	Seashore
596	Bird Tweet	Tweet
597	Telephone Ring	Telephone
598	Helicopter	Helicptr
599	Applause	Applause
600	Gunshot	Gunshot
601	Fall	Fall
DRUMS		
602	Standard Kit	StandKit
603	Rock Kit	RockKit
604	Electronic Kit	ElectKit
605	Dance Kit	DanceKit
606	TR-Drum-Kit-L	TR-Drum
607	IndiaKit-L	IndiaKit
608	NuIndiaKit-L	NuIndKit
609	R&B India-L	R&BIndia
610	IndoMix4-L	IndoMix4

Style List

NO.	English Name	LCD Name
8 BEAT		
1	Cosmic Pop	Cosm Pop
2	DiscoPop	DiscoPop
3	Bad Beat	Bad Beat
4	Mersey Rock	MerseyRk
5	Power Rock	Power Rk
6	Folk Rock	FolkRock
7	8 Beat 1	8Beat 1
8	8 Beat 2	8Beat 2
9	8 Beat 3	8Beat 3
10	60's 8 Beat	60's 8Bt
11	Guitar Pop	Gt Pop
12	Brit Pop	Brit Pop
13	Rock	Rock
14	Rock & Roll	RockRoll
15	Rock Shuffle	R.Shuffle
16	Hard Rock	HardRock
17	Pop Rock	PopRock
18	Fast Rock	FastRock
19	Sting Latin	StigLatn
20	Pop Fusion	Pop Fusn
21	8 Beat Rock	8Bt Rock
22	Blues	Blues
23	Blues Boogie	B.Boogie
24	Blues Shuffle	B.Shuffle
25	Blues Rock 1	BluRock1
26	Blues Rock 2	BluRcok2
16 BEAT		
27	16Beat Pop	16Bt Pop
28	Philly Pop	Phil Pop
29	16Beat Funk	16BtFunk
30	16Beat Dance	16BtDanc
31	16 Beat 1	16Beat 1
32	16 Beat 2	16Beat 2
33	16 Beat 3	16Beat 3
34	16 Beat Pop	16Bt Pop
35	16 Beat Shuffle	16BtShfl
36	Shuffle	Shuffle
37	Pop Shuffle	Pop Shfl
38	16Beat Soul	16BtSoul
39	Pop 16Beat 1	Pop16Bt1
40	Pop 16Beat 2	Pop16Bt2
41	Charleston	Charston
BALLAD & 6/8		
42	Nu Folk	Nu Folk
43	16 Beat Ballad	16BtBald
44	Pop Ballad 1	PopBald1
45	Pop Ballad 2	PopBald2
46	Love Ballad	LoveBald
47	Electro Pop	Ele Pop
48	8 Beat Ballad	8Bt Bald
49	Ballad	Ballad
50	Soul Blues	SoulBlue
51	Slow Ballad	SlowBald
52	Unplugged	Unplugged
53	Slow Rock 1	SlwRock1
54	Slow Rock 2	SlwRock2

55	6/8 Pop	6/8 Pop
56	12/8 Swing	12/8Swng
DANCE		
57	Euro Dance	EuroDanc
58	Progressive	Progress
59	Groove	Groove
60	Down Beat	DownBeat
61	Disco 1	Disco 1
62	Disco 2	Disco 2
63	Disco Party	DscParty
64	Disco Funk	DiscoFnk
65	Dance	Dance
66	Garage	Garage
67	House 1	House 1
68	House 2	House 2
69	Funky Pop	FunkyPop
70	Rap	Rap
71	Euro Beat	EuroBeat
72	Hip Hop	HipHop
73	Disco House	DscHouse
74	Club DJ	Club DJ
75	Techno	Techno
76	Twist	Twist
SOUL & FUNK		
77	Funk	Funk
78	Jazz Funk	JazzFunk
79	Cool Funky	CoolFunk
80	Soul 1	Soul 1
81	Soul 2	Soul 2
82	Soul Shuffle	SoulShfl
83	Pop Groove	PopGrove
84	R & B	R&B
85	Easy R&B Pop	EzR&BPop
86	6/8 Gospel	6/8Gospl
JAZZ		
87	Big Band	BigBand
88	Big Band Medium	BandMedi
89	Swing	Swing
90	Quick Step	QuickStp
91	Cool Jazz	CoolJazz
92	Acid Jazz	AcidJazz
93	Pop Swing	PopSwing
94	Swing Fox	SwingFox
95	Jazz Waltz	JazWaltz
96	Ragtime	Ragtime
97	Dixieland	Dixeland
LATIN		
98	Reggaeton 1	Regaton1
99	Reggaeton 2	Regaton2
100	Grupera Cumbia	Cumbia 1
101	Iztapa Cumbia	Cumbia 2
102	Norteno	Norteno
103	Mexican Salsa	SalsaMex
104	Salsa	Salsa
105	Merengue	Merengue
106	Tikitikita	Tikitkta
107	Cha Cha 1	ChaCha1
108	Pop Cha Cha	P.ChaCha

Style List

109	Rhumba	Rhumba
110	Pop Rhumba	P.Rhumba
111	Mambo	Mambo
112	Bossa Nova 1	Bossa 1
113	Bossa Nova 2	Bossa 2
114	Tango	Tango
115	Samba de Rua	SmbDeRua
116	Jazz Samba	JazSamba
117	Reggae	Reggae
118	New Reggae	NewRegga
119	Reggae Dance	DanRegga
120	Pop Reggae	P.Reggae
121	Meneito	Meneito
122	Pagode	Pagode
123	Arrastape	Arrastap
124	Forro	Forro
125	Baiao	Baiao
126	Sertanejo	Sertanjo
127	Xote	Xote
COUNTRY		
128	Country 1	Country1
129	Country 2	Country2
130	Pop Country	PopCntry
131	Country Rock	CtryRock
132	Country Folk	CtryFolk
133	3/4 Country	3/4Ctry
134	Country Waltz	C.Waltz
135	Country Shuffle	CtryShfl
136	Country Boogie	C.Boogie
137	Country Blues	C.Blues
138	Country Quick Step	CtryStep
139	Bluegrass	Bluegras
TRADITIONAL		
140	March 1	March 1
141	March 2	March 2
142	German March	G.March
143	6/8 March	6/8March
144	Polka	Polka
145	Pop Polka	PopPolka
146	Waltz	Waltz
147	Slow Waltz	SloWaltz
148	Vienna Waltz	VieWaltz
149	Musette	Musette
WORLD		
150	Dep/Rupak	Dep/Rupk
151	Dadra	Dadra
152	Bhajan	Bhajan
153	Keherwa	Keherwa
154	Ghazal	Ghazal
155	Aasamee	Aasamee
156	Koli Pattern	KoliPtn
157	South Pattern	SouthPtn
158	Dhamaal	Dhamaal
159	DesiRock	DesiRock
160	Sufi	Sufi
161	Filmy Masti	FilmyMst
162	Punjabi	Punjabi

163	Bhangra	Bhangra
164	Garba	Garba
165	Qawaali	Qawaali
166	Rajasthan	Rajsthan
167	Goa Masti	GoaMasti
168	Congo	Congo
169	Dangdut std	Dangduts
170	House Dangdut Koplo	Housdplo
171	Langgam Jawa	LanggamJ
172	Keroncongan	Kroncong
173	Keroncong Dangdut	CongDut
174	Batak	Batak
175	Minang	Minang
176	Pop Sunda	PopSunda
177	Bolero 1	Bolero 1
178	Bolero 2	Bolero 2
179	Bonton 1	Bonton 1
180	Bonton 2	Bonton 2
181	Cha Cha 2	ChaCha 2
182	Cha Dance	ChaDance
183	Dance Remix	DanceRmx
184	Disco Band	DiscoBnd
185	Rumba Pop	RumbaPop
186	Slow Rock 3	SlwRock3
187	Slow Surf	SlowSurf
188	Habanera	Habanera
189	Tango Cha	TangoCha
190	Chinese Folk Rock	ChFolkRk
191	Chinese R&B	ChnR&B
192	JiangNan Pop	JNanPop
193	Chinese Hip Hop	ChH-Hop
194	Chinese Techno	ChTechno
195	DaiZu Folk	DaiZu
196	XinJiang Dance	XinJiang
197	YunNan	YunNan
PIANIST		
198	Piano 8 Beat	Pno8Beat
199	Piano Ballad	PnoBalad
200	Piano Boogie	PnoBogie
201	Piano Jazz	PnoJazz
202	Piano Swing	PnoSwing
203	Piano Jazz Waltz	P.JWaltz
204	Piano Twist	PnoTwist
205	Piano March	PnoMarch
206	Piano 6/8 March	Pno6/8Mr
207	Piano Waltz	PnoWaltz

Song List

NO.	English Name	LCD Name
FOLK		
1	When The Saints Go Marching In	Marching
2	Aura Lea	AuraLea
3	Twinkle Twinkle Little Star	Twinkle
4	I've Been Working On The Railroad	WorkRail
5	Yankee Doodle	YankeeD
6	Michael Row The Boat Ashore	RowBoat
7	Auld Lang Syne	LangSyne
8	My Darling Clementine	Clemtine
9	Little Brown Jug	BrownJug
10	The House Of The Rising Sun	RiseSun
11	Danny Boy	DannyBoy
12	El Condor Pasa	EIcondor
13	Greensleeves	Sleeves
14	Heidenroslein	Heidenro
15	Wiegenlied 2	Wieglied2
16	Her Bright Smile Haunts Me Still	HerSmile
17	Old Black Joe	BlackJoe
18	Old Dog Tray	DogTray
19	Arirang	Arirang
20	The Quilting Party	TheParty
21	The Colorado Trail	TheTrail
22	I'D Like To Be In Texas	InTexas
23	Shenandoah	Shenando
24	Down In The Valley	Valley
25	On Top Of Old Smoky	TopSmoky
26	Barbara Allen	Allen
27	Careless Love	CaleLove
28	Sweet Betsy From Pike	SwetPike
29	Jesse James	James
30	The Cowboy's Lament	CowboyLa
ENTERTAINMENT		
31	Deck The Halls	DeckHall
32	Old Folks At Home	OldFolks
33	Camptown Races	C.Races
34	Oh! Susanna	Susanna
35	Jeanie With The Light Brown Hair	Jeanie
36	Long Long Ago	LongAgo
37	Annie Laurie	AnnieLa
38	My Old Kentucky Home	Kentucky
39	Turkey In The Straw	TukyStaw
40	Aloha Oe	AlohaOe
41	Carry Me Back To Old Virginny	Virginny
42	The Blue-Bells Of Scotland	BlueBell
43	Joy To The World	JoyWorld
44	Jingle Bells	JingBell
45	Battle Hymne Of The Republic	BatlHyme
46	Silent Night	SltNight
47	Ode To Joy	OdeToJoy
48	My Bonnie	MyBonnie
49	La Cucaracha	Cucarach
50	Yellow Rose Of Texas	YellRose
51	The Wabash Cannon Ball	CannBall
52	Red River Valley	RedRiver
53	Dreaming Of Home And Mother	Dreaming
54	Ring Ring De Banjo	DeBanjo
55	Der Freischutz	DerFreis

56	Tales Of Hoffman	Hoffman
57	Die Forelle	Forelle
KID'S SONG		
58	Skip To My Lou	SkipMyLo
59	London Bridge Is Falling Down	Bridge
60	Home On The Range	HomeRang
61	This Old Man	OldMan
62	Polly Wolly Doodle	PlyWlyDo
63	Sippin' Cider Through A Straw	SipinCid
64	Home Sweet Home	SwetHome
65	Mary Had A Little Lamb	MaryLamb
CLASSIC		
66	Chanson Du Toreador	Toreador
67	Meditation	Meditati
68	Wiegenlied	WieGenli
69	A Lover's Concerto	Concerto
70	Whispering Hope	Whisper
71	From The New World	NewWorld
72	O Sole Mio	OSoleMio
73	Auf Flugeln Des Gesanges	Gesanges
74	Santa Lucia	SantaLuc
75	Valse Brillante Op 34 #3 In F Major	ValOpFMr
76	Musette In D Major	MusetDMr
PIANO & KEYBOARD		
77	Yankee Doodle (Piano)	YankeeD2
78	Kaiser Walzer	Kaiser
79	From A Story Book	StoryBok
80	Hanon Piano Fingering 1	Hanon1
81	Hanon Piano Fingering 2	Hanon2
82	Hanon Piano Fingering 3	Hanon3
83	Hanon Piano Fingering 4	Hanon4
84	Hanon Piano Fingering 5	Hanon5
85	Hanon Piano Fingering 6	Hanon6
86	Hanon Piano Fingering 7	Hanon7
87	Basic Tutorial Beyer Piano 8	Beyer8
88	Basic Tutorial Beyer Piano 12	Beyer12
89	Basic Tutorial Beyer Piano 13	Beyer13
90	Basic Tutorial Beyer Piano 14	Beyer14
91	Basic Tutorial Beyer Piano 15	Beyer15
92	Basic Tutorial Beyer Piano 16	Beyer16
93	Basic Tutorial Beyer Piano 18	Beyer18
94	Basic Tutorial Beyer Piano 19	Beyer19
95	Basic Tutorial Beyer Piano 20	Beyer20
96	Cuckoo	Cuckoo
97	Basic Tutorial Beyer Piano 21	Beyer21
98	Basic Tutorial Beyer Piano 29	Beyer29
99	Butterfly	Buterfly
100	Basic Tutorial Beyer Piano 45	Beyer45
101	Christmas Eve	XmasEve
102	Basic Tutorial Beyer Piano 50	Beyer50
103	Basic Tutorial Beyer Piano 52	Beyer52
104	Basic Tutorial Beyer Piano 55	Beyer55
105	Basic Tutorial Beyer Piano 59	Beyer59
106	Beyer Eight Degrees Jump Etude	BeyrJump
107	Basic Tutorial Beyer Piano The Scale Of C Major	BeyerC
108	Basic Tutorial Beyer Piano 65	Beyer65
109	Basic Tutorial Beyer Piano 66	Beyer66

Song List

110	Old Folks At Home (Piano)	OldFolk2
111	Basic Tutorial Beyer Piano The Scale Of G Major	BeyerG
112	Basic Tutorial Beyer Piano 70	Beyer70
113	Basic Tutorial Beyer Piano 72	Beyer72
114	Basic Tutorial Beyer Piano 73	Beyer73
115	Basic Tutorial Beyer Piano 74	Beyer74
116	Larghetto	Larghetto
117	Minuet 2	Minuet2
118	Duke Aria From "The Rigoletto"	DukeAria
119	The Happy Farmer	HpFarmer
120	Dance Of The Four Swans From "Swan Lake"	SwanLake
121	Jesus Saviour Pilot Me	Jesus
122	Old Macdonald Had A Farm	OldAFarm
123	2-Part Invention No.13 In A Minor BWV 784	Invention
124	Musette	Musette
125	Bourree	Bourree
126	Carl Czerny 599 NO92	599No92
127	Away In A Manger	AwayInAM
128	Marriage Of Figaro	Marriage
129	Angels We Have Heard On High	Angles
130	Waltz	Waltz
131	Did You Ever See A Lassie	Lassie
132	Old France	OldFranc
133	Santa Claus Is Coming To Town	SantComn
134	Minuet 3	Minuet3
135	Alfredo And Violetta Column Tower Duet	Alfredo
136	Als Die Alte Mutter Mich Noch lehrte Singen	Mutter
137	Menuett G Dur 3	MenuettG
138	Knight	Knight
139	Gavotte	Gavotte
140	The Angels Singing	Singing

MIDI Implementation Chart

Function		Transmitted	Recognized	Remarks
Basic	Default	1ch	ALL	
Channel	Changed	x	x	
Mode	Default	x	1	
	Messages	x	x	
	Altered	*****	x	
Note	Note	12-114	0-127	
Number	: True Voice	*****	0-127	
Velocity	Note on	o 9nH,V=1-127	o 9nH,V=1-127	
	Note off	x (9nH,V=0)	o (9nH,V=0; 8nH,V=0-127)	
After	key's	x	x	
Touch	Ch's	x	x	
Pitch Bend		o	o	
Control	0,32	o	o	Bank Select
Change	1	x	o	Modulation
	5	x	x	Portamento Time
	6	x	o	Data Entry
	7	x	o	Volume
	10	x	o	Pan
	11	x	o	Expression
	64	o	o	Sustain Pedal
	65	x	x	Portamento On/Off
	66	x	o	Sostenuto Pedal
	67	x	o	Soft Pedal
	80	x	o	Reverb Program
	81	x	o	Chorus Program
	91	x	o	Reverb Level
	93	x	o	Chorus Level
	120	x	o	All Sound Off
	121	x	o	Reset All Controllers
	123	o	o	All Notes Off
Program		o	o	
Change	: True Number	*****	0-127	
System Exclusive		x	o	
System	: Song Position	x	x	
Common	: Song Select	x	x	
	: Tune	x	x	
System	: Clock	x	x	
Real Time	: Commands	x	x	
Aux	: Local On/Off	x	x	
Messages	: All Notes Off	o	o	
	: Active sense	x	o	
	: Reset	x	o	
Notes: *1				
When the accompaniment is started, an FAH message is transmitted.				
When the accompaniment is stopped, an FCH message is transmitted.				

- Mode 1: OMNI ON, POLY
- Mode 2: OMNI ON, MONO

- Mode 3: OMNI OFF, POLY
- Mode 4: OMNI OFF, MONO

- o: YES
- x: NO

 **Roland**