

MT-PowerAUDIO

▲ Warning ▲

In order to avoid electric shock, pls don't open the case cover. When the amplifier have problems, pls contact your agent or manufacturer repair it, you can also contact some Professional Staff repair it. Pls don't dismantle by non-specialized person, For fear of electrical accident and make sure the life safety.

◆ Thanks purchase our products. Please read the instruction before use and keep the manual.


MT-PowerAUDIO

STEREO AMPLIFIER

USER MANUAL

MA-100

Packing List



amplifier



user manual

Instruction

This machine is a lower impedance stereo amplifier. It has reliable protective device for short circuit, over load and overheat. This machine features high electrical performance index, stable reliability, easy operation and other advantages. It can be used for amplifying quality home theater, TV game, karaoke and back ground music.

Operation Remarks


In order to protect this machine, please note the following points:

- ❶ Do not expose the product to rain, high temperature or sunlight. And avoid getting water into the product via ventilation hole.
- ❷ Use the product only with the voltage specified on the unit.
- ❸ Do not operate the product in the place with high electromagnetic field.
- ❹ Ensure the earth terminal is connected to a proper ground for safety.
- ❺ If this machine has faults, please ask qualified professional to repair it.

Specifications

Model No.	MA-100
Output Power	2*100W MAX
Input	MIC x 2, Bluetooth, FM, SD, USB, Aux x 1
S/N Ratio	Mic: 90dB, AUX: 95dB
Volume adjustment	Bass: ±10dB / Treble: ±10dB
Impedance	8 ohm
Frequency Response	20 Hz - 20K Hz
Total Harmonic Distortion	<1% at 1KHz, 1/3 rated power
Power Supply	AC 220V/50Hz or 110V/60Hz
Product Dimension	280mm * 210mm * 90mm
Product Weight	4.5kg


Operation



- ❶ Bluetooth/SD/USB/FM Player
- ❷ MIC 1 Input
- ❸ MIC 2 Input
- ❹ Bass Volume Knob
- ❺ Treble Volume Knob
- ❻ Music Volume Knob
- ❼ MIC 1 Volume Knob
- ❽ MIC 2 Volume Knob
- ❾ Echo Volume Knob

- ❿ Left Channel (Channel 1) Volume Knob
- ⓫ Right Channel (Channel 2) Volume Knob
- ⓬ Power on/off button

Operation



- ❶ Power Cord
- ❷ Speaker Cable Terminal
- ❸ FM ANTENNA Terminal
- ❹ Line in Input Terminal